

請參考以下步驟來管理終端設備：

步驟 1. 登入路由器設定頁面，開啟網頁瀏覽器並前往 <http://cudy.net> 或 <http://192.168.10.1>

步驟 2. 系統狀態->終端設備->"詳情"

The screenshot shows the Cudy router management interface. At the top, there is a navigation bar with the Cudy logo and several menu items: '系統狀態' (System Status), '快速設定嚮導' (Quick Setup Wizard), '基本設定' (Basic Settings), '家長監護' (Parental Control), '進階設定' (Advanced Settings), and '診斷工具' (Diagnostic Tools). The '系統狀態' tab is selected and highlighted with a red box. Below the navigation bar, there is a central diagram showing the router (WR3000S) connected to the Internet (網際網路) and a Client (客戶端). To the right of the diagram, there is a red arrow pointing down to the 'Terminal Devices' (終端設備) section. This section contains a table with the following data:

終端設備		
終端設備	6	✓
2.4G WiFi	0	
5G WiFi	5	

Below the table, there is a '詳情' (Details) button, which is also highlighted with a red box.

步驟 3. 在狀態頁面會顯示目前路由器上所連的終端設備是透過有線、無線、2.4G、5G

系統狀態 / 終端設備		
狀態	終端設備	6
終端設備	2.4G WiFi	0
	5G WiFi	5
	有線	0
	Mesh	1

步驟 4. 在終端設備頁面顯示各設備資訊外，也能單獨管理設備的網路、VPN 等等

系統狀態 / 終端設備									
狀態	No.	主機名	IP / MAC位址	實時速率	信號	持續時間	網際網路	VPN	運作
終端設備	1	Mesh_4DAC Mesh	172.16.31.32 80:AF:CA:63	↑ 0.00 Kbps ↓ 0.00 Kbps	---	17:13:04	☒	☒	
	2	SLS2-SOFONG 5G WIFI	172.16.31.41 58:86:94:FC	↑ 10.51 Kbps ↓ 13.16 Kbps	45dB	01:38:40	☒	☒	
	3	iPhone 5G WIFI	172.16.31.60 B6:99:6F:4E	↑ 0.08 Kbps ↓ 0.09 Kbps	31dB	16:02:29	☒	☒	
	4	Watch 5G WIFI	172.16.31.155 02:F2:0A:93	↑ 0.00 Kbps ↓ 0.00 Kbps	28dB	01:20:52	☒	☒	
	5	Xiaomi-11-Lite-5... 5G WIFI	172.16.31.158 0E:B5:04:3B	↑ 0.00 Kbps ↓ 0.00 Kbps	30dB	01:55:05	☒	☒	
	6	Sofong-TSTW 5G WIFI	172.16.31.191 08:6A:C5:DE	↑ 0.58 Kbps ↓ 0.44 Kbps	37dB	00:16:54	☒	☒	

步驟 5. 點選"運作"後，會秀出設備資訊，也能更改設備名稱、限制速度

設備信息



MAC位址 B6:99:6F:4E:61:44

IP位址 172.16.31.60

在線時間 2025-05-19 18:52:25

設備名稱 (可選)

速率限制 ☒

下行速率 Mbps

上行速率 Mbps

保存&應用



服務電話 02-26588890 服務信箱 us-tw@sofong-int.com
台北市內湖區瑞光路583巷24號7樓